



Cube-S TX

发射器
Transmitter
使用手册
Instruction Manual

前言

感谢购买神牛产品！
欢迎使用神牛无线麦克风发射器Cube-S TX。本产品体积小、续航长，利用2.4GHz波段传输音频信号，适用于直播、采访、短视频、户外拍摄等多种场景。
使用本产品之前，请仔细阅读说明书，以便正确操作及使用。


主要特点：

- 全球通用频段2.4GHz 无线技术；
- 与接收器配对成功后无线距离最大可达300米（视距）；
- 无损音质，一键降噪；
- 内置锂电池，10小时长效续航；
- 配对后可遥控手机拍照/录像；

警告


- △ 麦克风是精密设备。请勿使其掉落或受到撞击，以避免发生故障。
- △ 请勿私自拆卸、改装或尝试维修本产品。产品如出现故障须由本公司或授权的维修人员进行检查维修。
- △ 请保持干燥，请勿用湿手握持本产品，亦不可将产品浸入水中或暴露于雨中。
- △ 请勿将本产品存放在阳光直射的地方、加热装置附近或者炎热、潮湿或多尘的地方。
- △ 请勿让儿童接触本产品，以避免发生意外。
- △ 请勿在易燃易爆环境中使用。在这些场合下，请注意相关警告标识。
- △ 请勿放置在超过50度的高温环境中。
- △ 请仔细阅读并遵守由厂商提供的警告或指示。

产品结构



1. 电源/降噪/配对键
2. 内置麦克风
3. 指示灯
4. 磁吸充电触点

包装清单



温馨提示：
说明书中的图片均为示意图，仅供参考。由于产品不断更新与升级，产品实物与图片可能存在差异，请以实物为准。

使用说明



- 长按2s开关机
- 开机30s内双击配对
- 短按一次开启/关闭降噪
- 配对成功后，在手机拍照/录像界面双击可遥控拍照/录像

将发射器从充电盒取出，自动开机；放入充电盒，则会自动关机。

倘发射器和接收器未配对成功，10s后都会退出配对状态。发射器超过5分钟未配对且其他无操作会自动关机。两个发射器与接收器配对成功后，如果其中一个发射器关机，对应的TX1/TX2指示灯会在30秒后熄灭。关机状态下，长按发射器和接收器的按键，可清除配对信息，指示灯会白色快闪3s。

遥控手机拍照/录像时，如手机不在拍照/录像界面，双击发射器按键，则会触发手机音量弹窗界面，属正常现象。如手机打开了APP功能则无法触发拍照/录像功能。

指示灯状态	意义
发射器绿色闪烁（亮0.5s/灭0.5s）	开机未配对
发射器绿色快闪（亮0.25s/灭0.25s）	正在配对
发射器绿色长亮	配对成功
发射器指示灯橙色长亮	开启降噪

充电

充电线充电

将发射器通过磁吸充电线连接电源即可为自身充电。

指示灯状态	意义
发射器蓝色闪烁	充电中
发射器蓝色长亮	充满电
发射器红色闪烁（亮0.5s/灭0.5s）	发射器电量低于10%

充电盒充电

将产品放入充电盒内并打开盒盖时：首先检测发射器是否插入对应凹槽内，顶针接触到发射器的充电触点后，然后检测是否为满电状态，如果不满电则开始充电直至充满。开盖后充电盒上的指示灯亮起，关盖五秒后熄灭。

将产品放入充电盒内并关上盒盖时：发射器进入关机状态并充电，充满电后不再补充电量。

规格参数

名称	发射器
型号	Cube-S TX
传输类型	2.4GHz数字跳频系统
拾音模式	全向型
频率范围	20Hz~20KHz
最大SPL	115dB
信噪比	> 70dB
最大无线距离	300米（视距）
锂电池参数	3.87V, 97mAh, 0.376Wh
输入参数	5V = 90mA
续航时间	约10小时
充电时间	约1.5小时
工作环境温度	-10~50℃
充电环境温度	0~45℃
尺寸	24.5mm x24.8mm x12.5mm
净重	7g

规格参数如有变更，恕不另行通知。

维护保养

避免跌落：如果受到强烈碰撞或振动，设备可能会发生故障。

保持干燥：本产品是非防水产品，如果将其浸入水中或放置于高湿度的环境中将可能发生故障。内部构造生锈可能会导致无法修理的损害。

避免温度骤变：温度的突变，诸如在寒冷天进出温暖的大楼将可能会使产品内部结露。为避免结露，请将本产品事先装入手提袋或塑料袋内，以防湿度突变。

远离强磁场：无线电广播发射机等设备产生的强静电或强磁场可能会导致本产品正常工作。

如有技术更改，恕不另行通知。

产品保修

尊敬的用户，本保修卡是申请保修服务的重要凭证，请您配合销售商填写并妥善保管，谢谢！

产品信息	型号	产品条码
	姓名	联系电话
用户信息	通信地址	
销售商信息	名称	
	联系电话	
	通信地址	
	销售日期	
备注		

注：此表应由销售商盖章确认。

产品信息

本产品适用于相关《产品保修信息》(见后面说明)所列产品，其他非属此范围的产品或部件（如促销品、赠品及其他出厂后附加的部件等）不在此保修承诺内。

保修期

产品及部件的相应保修期按相关的《产品保修信息》执行。保修期自产品首次购买日起算，购买日以购买产品时保修卡登记日期为准。

如何获得保修服务

要保修服务，您可直接与产品销售商或授权服务机构联系，也可拨打神牛产品售后服务电话，与我们联系，由我们的服务人员为您安排服务。申请保修时，您应提供有效的保修卡作为保修凭证，方可获得保修。如您不能提供有效的保修卡，则在我们可确认产品或部件属于保修范围的情况下，也可以为您提供保修，但这不作为我们的义务。

不适用保修的情况

如产品存在下列情况，本文件项下的保证和服务将不适用 ① 产品或部件超过相应保修期；② 错误或不适当使用、维护或保管导致的故障或损坏，如：不当搬运；非按产品合理预期用途使用；不当插拔外接设备；跌落或外力挤压；接触或暴露于不适当温度、溶剂、酸碱、水浸或潮湿环境；③ 由非神牛授权机构或人员安装、修理、更改、添加或拆卸造成的故障或损坏；④ 产品或部件原有识别信息被非更改或删除；⑤ 无有效保修卡；⑥ 使用非法授权、非标准或非公开发行的软件造成的故障或损坏；⑦ 因不可抗力或意外事件造成的故障或损坏；⑧ 其他非因产品本身质量问题导致的故障或损坏。遇上述情况，您应向相关责任方寻求解决，神牛对此不承担任何责任。因非在保修期或保修范围内的部件、附件或软件导致产品不能正常使用的，不是保修范围内的故障。产品使用过程中正常的脱色，磨损和消耗，不是保修范围内的故障。

产品保修和服务支持信息

产品的保修期和服务类型按以下《产品保修信息》执行：

产品类别	选项名称	保修期(月)	保修服务类型
部件	电路板	12	客户送修
	电池	3	客户送修
	充电器等带电性能的部件	12	客户送修
其他	如电池盒、防风棉、防风毛罩、锁紧装置、手提绳、扎带、魔术贴、领夹、便携袋、包装等	无	无保修

神牛产品售后服务电话 0755-29609320-8062



深圳市神牛摄影器材有限公司
地址：深圳市宝安区福海街道地展社区福川工业区厂房2栋 电话：0755-29609320(8062)
传真：0755-25723423 邮箱：godox@godox.com

GODOX Photo Equipment Co., Ltd.
Add: Building 2,Yaochuan Industrial Zone, Tangwei Community, Fuhai Street, Bao'an District, Shenzhen 518103, China Tel: +86-755-29609320(8062) Fax: +86-755-25723423
E-mail: godox@godox.com

www.godox.com
Made in China I 705-CSTX00-00



Foreword

Thank you for purchasing!

Cube-S TX is the transmitter of Godox's latest wireless microphone system. With the characteristics of compact and portable, long duration of use, as well as 2.4GHz wireless transmission, it's quite suitable for live streaming, interview, short video recording, outdoor shooting, etc.

Please read this manual carefully before using to make sure the correct operation and exert the optimum function.


Main Feature

- Globally universal 2.4GHz wireless transmission technology.
- The maximum wireless transmission distance up to 300m (sight distance) after paired with receiver.
- Clear and stable sound quality with denoise function.
- Built-in lithium battery provides 10h of long working time.
- Shooting/Recording through remote control after paired with receiver.

Warning


- ⚠ This product is high-precision instrument, please avoid falling, collision or pounding.
- ⚠ Do not disassemble. Should repairs become necessary, this product must be sent to our Company or an authorized maintenance center.
- ⚠ Always keep this product dry. Do not use in rain or damp conditions.
- ⚠ Do not leave or store this product in the environment of direct sunlight, near heating devices, or in hot, humid or dusty.
- ⚠ Keep out of reach of children.
- ⚠ Do not use in flammable and explosive environments. Pay attention to the relevant warning signs.
- ⚠ Do not leave or store the product if the ambient temperature reads over 50°C.
- ⚠ Please read carefully and follow the warnings or instructions provided by the manufacturer.

Structure of Product



1. Power Switch/Denoise/Pairing Button
2. Built-in Microphone
3. Indicator
4. Magnetic Charging Points

What's Inside



Note:

Due to continuous updates and upgrades of the products, there may be differences between the actual products and the pictures. Therefore, the pictures are for reference only, products to prevail in kind.

Instructions for Use



- Long press for 2s to turn on/off
- Double press within 30s after power on to pair
- Short press once to turn on/off denoise

function

- In paired status, double press to take a picture or record when the smartphone's camera is turned on

Take out the transmitter from the charging case, it will boot up automatically, while put it into the charging case, it will be turned off.

The transmitter and receiver will exit pairing status after 10s if unpaired. The transmitter will turn off automatically if it has not been paired for more than 5min and no other operations. If two transmitters are paired with the receiver but one of which is turned off later, then its corresponding TX1/TX2 indicator will be off in 30s. In the power-off state, press and hold the buttons of the transmitter and receiver to clear the pairing information, and the indicators will flash white rapidly for 3s.

If the smartphone is not in the camera interface, double press the transmitter button, the volume pop-up interface will be triggered, which is normal. If the smartphone has turned on an app function, the shooting/recording function cannot be triggered.

Indicator Status	Meaning
Indicator of transmitter flashes green every 0.5s	Unpaired after powered on
Indicator of transmitter flashes green rapidly every 0.25s	Pairing status
Indicator of transmitter is constant on green	Successfully paired
Indicator of transmitter is constant on orange	Denoise function is on

Charging

Charging through Charging Cable

The transmitter can be charged after connecting to power source through magnetic charging cable.

Indicator Status	Meaning
Indicator of transmitter flashes blue	Charging
Indicator of transmitter is constant on blue	Fully charged
Indicator of transmitter flashes red every 0.5s	Battery level of transmitter is below 10%

Charging through Charging Cable

Put the devices into the charging case and open the lid: The case will first detect whether the transmitters are correctly inserted into the corresponding slots, if the pins inside touched the charging points of the transmitters, it will detect whether the transmitters are fully charged, if not, it will start charging until the transmitters are fully charged. The indicators on the charging case will light up if the lid is open, and turn off after the lid is closed.

Put the devices into the charging case and close the lid: The transmitters will shut down and be charged until they are fully charged.

Technical Data

Name	Transmitter
Model	Cube-S TX
Transmission Type	2.4GHz Frequency Hopping System
Pickup Pattern	Omnidirectional
Frequency Range	20Hz-20KHz
Max. SPL	115dB
SNR	> 70dB

Max. Wireless Distance	300m (sight distance)
Lithium Battery Parameters	3.87V, 97mAh, 0.376Wh
Input Parameters	5V = 90mA
Working Time	Approx. 10h
Charging Time	Approx. 1.5h
Working Environment Temperature	-10~50°C
Charging Environment Temperature	0~45°C
Dimension	0.96" x 0.98" x 0.49"
Net Weight	7g

Specifications and data may subject to changes without notice.

Maintenance

Avoid falling. Strong collision or vibration may malfunction the device.

Keep dry. This product is not water-proof. Malfunction, rust, and corrosion may occur and go beyond repair if soaked in water or exposed to high humidity.

Avoid sudden temperature changes. Condensation happens in sudden temperature changes such as the circumstance when taking the product out of a building with higher temperature to outside in winter. Please put the product in a handbag or plastic bag beforehand.

Keep away from strong magnetic field. The strong static or magnetic field produced by devices such as radio transmitters leads to malfunction.

Specifications and data may subject to changes without notice.

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Warning

Operating frequency: 2402MHz - 2480MHz

Maximum EIRP Power: -4.25dBm

Declaration of Conformity

GODOX Photo Equipment Co., Ltd. hereby declares that this equipment are in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU. In accordance with Article 10(2) and Article 10(10), this product is allowed to be used in all EU member states. For more information of DoC, Please click this web link: <https://www.godox.com/eu-declaration-of-conformity>

The device complies with RF specifications when the device used at 0mm from your body.



Warranty

Dear customers, as this warranty card is an important certificate to apply for our maintenance service, please fill in the following form in coordination with the seller and safe-keep it. Thank you!

Product Information	Model	Product Code Number
Customer Information	Name	Contact Number
	Address	
Seller Information	Name	
	Contact Number	
	Address	
	Date of Sale	
Note		

Note: This form shall be sealed by the seller.

Applicable Products

The document applies to the products listed on the Product Maintenance Information (see below for further information). Other products or accessories (e.g. promotional items, giveaways and additional accessories attached, etc.) are not included in this warranty scope.

Warranty Period

The warranty period of products and accessories is implemented according to the relevant Product Maintenance Information. The warranty period is calculated from the day (purchase date) when the product is bought for the first time, and the purchase date is considered as the date registered on the warranty card when buying the product.

How to Get the Maintenance Service

If maintenance service is needed, you can directly contact the product distributor or authorized service institutions. You can also contact the Godox after-sale service call and we will offer you service. When applying for maintenance service, you should provide valid warranty card. If you cannot provide valid warranty card, we may offer you maintenance service once confirmed that the product or accessory is involved in the maintenance scope, but that shall not be considered as our obligation.

Inapplicable Cases

The guarantee and service offered by this document are not applicable in the following cases: ①. The product or accessory has expired its warranty period; ②. Breakage or damage caused by inappropriate usage, maintenance or preservation, such as improper packing, improper usage, improper plugging in/out external equipment, falling off or squeezing by external force, contacting or exposing to the improper temperature, solvent, acid, base, flooding and damp environments, etc.; ③. Breakage or damage caused by non-authorized institution or staff in the process of installation, maintenance, alteration, addition and detachment; ④. The original identifying information of product or accessory is modified, alternated, or removed; ⑤. No valid warranty card; ⑥. Breakage or damage caused by using illegally authorized, nonstandard or non-public released software; ⑦. Breakage or damage caused by force majeure or accident; ⑧. Breakage or damage that could not be attributed to the product itself. Once met these situations above, you should seek solutions from the related responsible parties and Godox assumes no responsibility. The damage caused by parts, accessories and software that beyond the warranty period or scope is not included in our maintenance scope. The normal discoloration, abrasion and consumption are not the breakage within the maintenance scope.

Maintenance and Service Support Information

The warranty period and service types of products are implemented according to the following Product Maintenance Information.

Product Type	Name	Maintenance Period(month)	Warranty Service Type
Parts	Product Main Body	12	Customer sends the product to designated site
	Battery	3	Customer sends the product to designated site
	Charger, Electrical Parts etc.	12	Customer sends the product to designated site
Other Items	Battery Case, Windscreen Foam, Wind Cap, Locking Device, Lanyard, Tie, Velcro Tape, Clip, Bag, Package etc.	No	Without warranty

Godox After-sale Service Call: 0755-29609320-8062