

Compatible Camera Models of Godox X Series Flash Triggers

Compatible Nikon Camera Models

XPRO II N , X2T-N , Xpro-N , X1N Transmitter & Receiver Flash Units

Mode	Type	TTL Flash			M Flash			Multi Flash	Auto Focus Assist Beam	Note	
		Standard	REAR	HSS(FP)	Standard	REAR	HSS(FP)				
D800	SLR Cameras	✓	✓	✓	✓	✓	✓	✓	✓		
D780		✓	✓	✓	✓	✓	✓	✓	✓		
D5		✓	✓	✓	✓	✓	✓	✓	✓		
D4		✓	✓	✓	✓	✓	✓	✓	✓		
D500		✓	✓	✓	✓	✓	✓	✓	✓		
D610		✓	✓	✓	✓	✓	✓	✓	✓		
D750		✓	✓	✓	✓	✓	✓	✓	✓		
D700		✓	✓	✓	✓	✓	✓	✓	✓		
D300S		✓	✓	✓	✓	✓	✓	✓	✓		
D3300		✓	✓	Unavailable	✓	✓	Unavailable	✓	✓		
D3100		✓	✓		✓	✓		✓	✓	✓	
D5300		✓	✓		✓	✓		✓	✓	✓	
D5200		✓	✓		✓	✓		✓	✓	✓	
D5000		✓	✓		✓	✓		✓	✓	✓	
Z7II		✓	✓		✓	✓		✓	✓	✓	
Z6	✓	✓	✓	✓	✓	✓	✓				
Z8	✓	✓	✓	✓	✓	✓	✓	Unavailable	Dark edges exist at a shutter speed of 1/250 in both high-speed and low-speed.		
Z9	✓	✓	✓	✓	✓	✓	✓				
ZFC	✓	✓	✓	✓	✓	✓	✓				

Note: Please set the cameras to high-speed auto shutter when using high-speed.

X3 N Transmitter & Receiver Flash Units

Mode	Type	TTL Flash			M Flash			Multi Flash	Note	
		Standard	REAR	HSS(FP)	Standard	REAR	HSS(FP)			
D800	SLR Cameras	✓	✓	✓	✓	✓	✓	✓		
D780		✓	✓	✓	✓	✓	✓	✓		
D5		✓	✓	✓	✓	✓	✓	✓		
D4		✓	✓	✓	✓	✓	✓	✓		
D500		✓	✓	✓	✓	✓	✓	✓		
D610		✓	✓	✓	✓	✓	✓	✓		
D750		✓	✓	✓	✓	✓	✓	✓		
D700		✓	✓	✓	✓	✓	✓	✓		
D300S		✓	✓	✓	✓	✓	✓	✓		
D3300		✓	✓	Unavailable	✓	✓	Unavailable	✓		
D3100		✓	✓		✓	✓		✓	✓	
D5300		✓	✓		✓	✓		✓	✓	
D5200		✓	✓		✓	✓		✓	✓	
D5000		✓	✓		✓	✓		✓	✓	
Z7II		✓	✓		✓	✓		✓	✓	✓
Z6	✓	✓	✓	✓	✓	✓	✓			
Z8	✓	✓	✓	✓	✓	✓	✓	Unavailable	Dark edges exist at a shutter speed of 1/250 in both high-speed and low-speed.	
Z9	✓	✓	✓	✓	✓	✓	✓			
ZFC	✓	✓	✓	✓	✓	✓	✓			

Note: Please set the cameras to high-speed auto shutter when using high-speed.

Compatible Pentax Camera Models

XProP Transmitter & Receiver Flash Units

Mode	Type	TTL Flash			M Flash			Multi Flash	Auto Focus Assist Beam	Note
		Standard	REAR	HSS(FP)	Standard	REAR	HSS(FP)			
K-3II	New Cameras	✓	Unavailable	✓	Unavailable	Unavailable	✓	✓		
645Z		✓		✓			✓			
KP		✓		✓			✓			
K-70		✓		✓			✓			
K-S1		✓		✓			✓			
K-S2		✓		✓			✓			

Compatible Canon Camera Models

XPRO II C , X2T-C , Xpro-C , X1C Transmitter & Receiver Flash Units

Mode	Type	TTL Flash			M Flash			Multi Flash	Single-group Mode Camera Setting	Auto Focus Assist Beam	Note
		Standard	REAR	HSS(FP)	Standard	REAR	HSS(FP)				
5DIII	SLR Cameras	✓	✓	✓	✓	✓	✓	✓	✓	✓	
5DIV		✓	✓	✓	✓	✓	✓	✓	✓	✓	
70D		✓	✓	✓	✓	✓	✓	✓	✓	✓	
80D		✓	✓	✓	✓	✓	✓	✓	✓	✓	
1DX		✓	✓	✓	✓	✓	✓	✓	✓	✓	
850D		✓	✓	✓	✓	✓	✓	✓	✓	✓	
760D		✓	✓	✓	✓	✓	✓	✓	✓	✓	
5DII		✓	✓	✓	✓	✓	✓	✓	✓	✓	
7DII		✓	✓	✓	✓	✓	✓	✓	✓	✓	
6DII		✓	✓	✓	✓	✓	✓	✓	✓	✓	
6D		✓	✓	✓	✓	✓	✓	✓	✓	✓	
800D		✓	✓	✓	✓	✓	✓	✓	✓	✓	
90D		✓	✓	✓	✓	✓	✓	✓	✓	✓	
600D		✓	✓	✓	✓	✓	✓	✓	✓	✓	
7D		✓	✓	✓	✓	✓	✓	✓	✓	✓	
200DII		✓	✓	✓	✓	✓	✓	✓	Unavailable	✓	
3000D		✓	✓	✓	✓	✓	✓	✓	Unavailable	Unavailable	Dark edges exist at a shutter speed of 1/250 in both high-speed and low-speed.
1500D		✓	✓	✓	✓	✓	✓	✓			
M5		✓	✓	✓	✓	✓	✓	✓			
M3		✓	✓	✓	✓	✓	✓	✓	Unavailable	Unavailable	Dark edges exist at a shutter speed of 1/250 in both high-speed and low-speed.
EOS RP	✓	✓	✓	✓	✓	✓	✓				
EOS R	✓	✓	✓	✓	✓	✓	✓				
R5	✓	✓	Unavailable	✓	✓	✓	✓				
R6II	✓	✓		✓	✓	✓	✓				
R7	✓	✓		✓	✓	✓	✓				
R50	✓	✓		✓	✓	✓	✓				
R3	✓	✓	✓	✓	✓	✓	✓	✓	Workable with flash trigger after connecting to an adapter.		

X3 C Transmitter & Receiver Flash Units

Mode	Type	TTL Flash			M Flash			Multi Flash	Single-group Mode Camera Setting	Note	
		Standard	REAR	HSS(FP)	Standard	REAR	HSS(FP)				
5DIII	SLR Cameras	✓	✓	✓	✓	✓	✓	✓	✓		
5DIV		✓	✓	✓	✓	✓	✓	✓	✓		
70D		✓	✓	✓	✓	✓	✓	✓	✓		
80D		✓	✓	✓	✓	✓	✓	✓	✓		
1DX		✓	✓	✓	✓	✓	✓	✓	✓		
850D		✓	✓	✓	✓	✓	✓	✓	✓		
760D		✓	✓	✓	✓	✓	✓	✓	✓		
5DII		✓	✓	✓	✓	✓	✓	✓	✓		
7DII		✓	✓	✓	✓	✓	✓	✓	✓		
6DII		✓	✓	✓	✓	✓	✓	✓	✓		
6D		✓	✓	✓	✓	✓	✓	✓	✓		
800D		✓	✓	✓	✓	✓	✓	✓	✓		
90D		✓	✓	✓	✓	✓	✓	✓	✓		
600D		✓	✓	✓	✓	✓	✓	✓	✓		
7D		✓	✓	✓	✓	✓	✓	✓	✓		
200DII		✓	✓	✓	✓	✓	✓	✓	Unavailable	✓	
3000D		✓	✓	✓	✓	✓	✓	✓	Unavailable	Unavailable	Dark edges exist at a shutter speed of 1/250 in both high-speed and low-speed.
1500D		✓	✓	✓	✓	✓	✓	✓			
M5		✓	✓	✓	✓	✓	✓	✓			
M3		✓	✓	✓	✓	✓	✓	✓	Unavailable	Unavailable	Dark edges exist at a shutter speed of 1/250 in both high-speed and low-speed.
EOS RP	✓	✓	✓	✓	✓	✓	✓				
EOS R	✓	✓	✓	✓	✓	✓	✓				
R5	✓	✓	Unavailable	✓	✓	✓	✓				
R6II	✓	✓		✓	✓	✓	✓				
R7	✓	✓		✓	✓	✓	✓				
R50	✓	✓		✓	✓	✓	✓				
R3	✓	✓	✓	✓	✓	✓	✓	✓	Workable with flash trigger after connecting to an adapter.		

Compatible FUJIFILM Camera Models

XPRO II F、X2T-F、Xpro-F、X1T-F Transmitter & Receiver Flash Units

Mode	Type	TTL Flash			M Flash			Multi Flash	Auto Focus Assist Beam	Note	
		Standard	REAR	HSS(FP)	Standard	REAR	HSS(FP)				
X-Pro2	A	✓	✓	✓	✓	✓	✓	✓	✓		
X-T20		✓	✓	✓	✓	✓	✓	✓	✓		
X-T2		✓	✓	✓	✓	✓	✓	✓	✓		
X-T1		✓	✓	✓	✓	✓	✓	✓	✓		
GFX50s		✓	✓	✓	✓	✓	✓	✓	✓		
GFX50R		✓	✓	✓	✓	✓	✓	✓	✓		
X-T30		✓	✓	✓	✓	✓	✓	✓	✓		
X-T4		✓	✓	✓	✓	✓	✓	✓	✓		
X-T3		✓	✓	✓	✓	✓	✓	✓	✓		
X-T50		✓	✓	✓	✓	✓	✓	✓	✓		
X-H2		✓	✓	✓	✓	✓	✓	✓	✓		
X-Pro1		B	✓	✓	Unavailable	✓	✓	Unavailable	✓	Unavailable	1. These cameras do not have high-speed shooting mode. 2. M mode can not adjust front-curtain, rear-curtain and settings of the cameras.
X-T10			✓	✓		✓	✓				
X-E1			✓	✓		✓	✓				
X-A3	✓		✓	✓		✓					
X100F	C	✓	✓	Unavailable	✓	✓	Unavailable	✓	Unavailable	The camera does not have rear-curtain and high-speed shooting mode.	
X100T		✓	Unavailable		✓	Unavailable		✓			

X3 F Transmitter & Receiver Flash Units

Mode	Type	TTL Flash			M Flash			Multi Flash	Note	
		Standard	REAR	HSS(FP)	Standard	REAR	HSS(FP)			
X-Pro2	A	✓	✓	✓	✓	✓	✓	✓		
X-T20		✓	✓	✓	✓	✓	✓	✓		
X-T2		✓	✓	✓	✓	✓	✓	✓		
X-T1		✓	✓	✓	✓	✓	✓	✓		
GFX50s		✓	✓	✓	✓	✓	✓	✓		
GFX50R		✓	✓	✓	✓	✓	✓	✓		
X-T30		✓	✓	✓	✓	✓	✓	✓		
X-T4		✓	✓	✓	✓	✓	✓	✓		
X-T3		✓	✓	✓	✓	✓	✓	✓		
X-T50		✓	✓	✓	✓	✓	✓	✓		
X-H2		✓	✓	✓	✓	✓	✓	✓		
X-Pro1		B	✓	✓	Unavailable	✓	✓	Unavailable	✓	1. These cameras do not have high-speed shooting mode. 2. M mode can not adjust front-curtain, rear-curtain and settings of the cameras.
X-T10			✓	✓		✓	✓			
X-E1			✓	✓		✓	✓			
X-A3	✓		✓	✓		✓				
X100F	C	✓	✓	Unavailable	✓	✓	Unavailable	✓	The camera does not have rear-curtain and high-speed shooting mode.	
X100T		✓	Unavailable		✓	Unavailable		✓		

Compatible Olympus and Panasonic Camera Models

X3 O、XPRO II O、X2T-O、Xpro-O、X1T-O Transmitter & Receiver Flash Units

Mode	Type	TTL Flash			M Flash			Multi Flash	Note
		Standard	REAR	HSS(FP)	Standard	REAR	HSS(FP)		
E-M1	Olympus	✓	✓	✓	✓	✓	✓	✓	
PRN-F		✓	✓	✓	✓	✓	✓	✓	
E-M10II		✓	✓	✓	✓	✓	✓	✓	
E-M10III		✓	✓	✓	✓	✓	✓	✓	
E-PL8		✓	✓	✓	✓	✓	✓	✓	
E-P5		✓	✓	✓	✓	✓	✓	✓	
E-M5II		✓	✓	✓	✓	✓	✓	✓	
GH4		✓	✓	✓	✓	✓	✓	✓	
LX100		✓	✓	✓	✓	✓	✓	✓	
GFT1		✓	✓	✓	✓	✓	✓	✓	
GH5	Panasonic	✓	✓	✓	✓	✓	✓	✓	
GX85		✓	✓	✓	✓	✓	✓	✓	Bright edges exist in high-speed mode.
FZ2500GX		✓	✓	✓	✓	✓	✓	✓	
S1		✓	✓	✓	✓	✓	✓	✓	Bright edges exist in high-speed mode.

Note: 1. This table only lists the tested camera models, not all cameras. For the compatibility of other camera models, a self-test is recommended.
2. Rights to modify this table are retained.

Compatible Sony Camera Models

XPRO II S、X2T-S、Xpro-S、X1S Transmitter & Receiver Flash Units

Mode	Type	TTL Flash			M Flash			Multi Flash	Auto Focus Assist Beam	Note	
		Standard	REAR	HSS(FP)	Standard	REAR	HSS(FP)				
A7III	Mirrorless Cameras	✓	✓	✓	✓	✓	✓	✓	✓		
A7IV		✓	✓	✓	✓	✓	✓	✓	✓		
A7R5		✓	✓	✓	✓	✓	✓	✓	✓		
A7RIII		✓	✓	✓	✓	✓	✓	✓	✓		
A7RIV		✓	✓	✓	✓	✓	✓	✓	✓		
A9		✓	✓	✓	✓	✓	✓	✓	✓		
A7RII/V4.0		✓	✓	✓	✓	✓	✓	✓	✓		
A7R		✓	✓	✓	✓	✓	✓	✓	✓		
A6400		✓	✓	✓	✓	✓	✓	✓	✓	Unavailable	
A6700		✓	✓	✓	✓	✓	✓	✓	✓		
A6000		✓	✓	✓	✓	✓	✓	✓	✓		
RX10		Cameras with Fixed Lens	✓	✓	✓	✓	✓	✓	✓		
A99		SLR Cameras	✓	✓	✓	✓	✓	✓	✓	✓	
A77			✓	✓	✓	✓	✓	✓	✓	✓	
A77II	✓		✓	✓	✓	✓	✓	✓	✓		
A350	✓		✓	✓	✓	✓	✓	✓	✓		

X3 S Transmitter & Receiver Flash Units

Mode	Type	TTL Flash			M Flash			Multi Flash	Note	
		Standard	REAR	HSS(FP)	Standard	REAR	HSS(FP)			
A7III	Mirrorless Cameras	✓	✓	✓	✓	✓	✓	✓		
A7IV		✓	✓	✓	✓	✓	✓	✓		
A7R5		✓	✓	✓	✓	✓	✓	✓		
A7RIII		✓	✓	✓	✓	✓	✓	✓		
A7RIV		✓	✓	✓	✓	✓	✓	✓		
A9		✓	✓	✓	✓	✓	✓	✓		
A7RII/V4.0		✓	✓	✓	✓	✓	✓	✓		
A7R		✓	✓	✓	✓	✓	✓	✓		
A6400		✓	✓	✓	✓	✓	✓	✓		
A6700		✓	✓	✓	✓	✓	✓	✓		
A6000		✓	✓	✓	✓	✓	✓	✓		
RX10		Cameras with Fixed Lens	✓	✓	✓	✓	✓	✓	✓	
A99		SLR Cameras	✓	✓	✓	✓	✓	✓	✓	
A77			✓	✓	✓	✓	✓	✓	✓	
A77II	✓		✓	✓	✓	✓	✓	✓		
A350	✓		✓	✓	✓	✓	✓	✓		

Compatible Leica Camera Models

XProII. Transmitter & Receiver Flash Units

Mode	Type	TTL Flash			M Flash			Multi Flash	Auto Focus Assist Beam	Note
		Standard	REAR	HSS(FP)	Standard	REAR	HSS(FP)			
SL1	New Cameras	✓	✓	✓	✓	✓	✓	✓	✓	Misfire flashes exist in continuous flash.
SL2		✓	✓	✓	✓	✓	✓	✓	✓	Bright edges exist at high-speed shooting.
M10		✓	✓	✓	✓	✓	✓	✓	✓	
Q2		✓	✓	✓	✓	✓	✓	✓	✓	
TYP601		✓	✓	✓	✓	✓	✓	✓	✓	Misfire flashes exist in continuous flash.

X3 L Transmitter & Receiver Flash Units

Mode	Type	TTL Flash			M Flash			Multi Flash	Note
		Standard	REAR	HSS(FP)	Standard	REAR	HSS(FP)		
SL1	New Cameras	✓	✓	✓	✓	✓	✓	✓	Misfire flashes exist in continuous flash.
SL2		✓	✓	✓	✓	✓	✓	✓	Bright edges exist at high-speed shooting.
M10		✓	✓	✓	✓	✓	✓	✓	
Q2		✓	✓	✓	✓	✓	✓	✓	
TYP601		✓	✓	✓	✓	✓	✓	✓	✓