

V4800 固件说明

- 一、请使用神牛固件升级软件 G3 V1.1 及以上版本打开该固件进行升级，G3 可在官网下载。
- 二、版本号查看方法：开机后，进入菜单界面，在最后面找到设备信息，可以看到软件版本号（如 1.00 版本：V1.00）。
- 三、版本说明：

版本	更新内容	日期
V1.01	取消触屏长按解除锁定功能	25/7/14
V1.03	新增功能：屏幕锁定掉电存储。可在菜单中关闭开机锁定，开机无需解锁。菜单增加无线引闪距离，可选择近距离引闪。	26/2/5

注：详细规格请在官网（www.godox.com.cn）下载最新说明书。

V4800 Firmware Release Note

- Please use Godox firmware upgrade software G3 V1.1 or later to open this firmware file to proceed with the upgrade. G3 can be downloaded on the official website.
- How to check the version number:After the device is powered on, go to the menu page and find the device information at the very end. You can see the software version number (e.g. Version 1.00: V1.00).
- Version Instructions:

Version	What's New	Date
V1.01	Disable the long-press touch screen unlock function.	25/7/14
V1.03	New Features: Screen lock power-off memory.Support disabling power-on lock in the menu (no unlock required on startup).Added wireless flash triggering distance options in the menu, allowing selection of short-range triggering.	26/2/5

Note: For more details, please download the newest instruction manual on the official website: www.godox.com.