Compatible Camera Models of Godox Camera Flashes and Macro Flashes

Compatible Canon Camera Models

Godox Camera Flashes: V1ProC、V1C、V860IIIC、V350C、TT685IIC、TT685C、TT350C
Godox Macro Flashes: MF-R76C

| Mode | Type | Camera Flashes | | | | | | | 2.4G Transmitter & Receiver Flash Units | | | | | | | Auto Focus Assist Beam | Gr Mode | Note |
| | | TTL Flash | | | M Flash | | | Multi Flash | TTL Flash | | | M Flash | | | Multi Flash | | | |
		Front-curtain Sync	Rear-curtain Sync	HSS	Front-curtain Sync	Rear-curtain Sync	HSS		Front-curtain Sync	Rear-curtain Sync	HSS	Front-curtain Sync	Rear-curtain Sync	HSS				
80D	SLR Cameras	√	√	√	√	√	√	√	√	√		√	√	√	√	√	√	
90D		√	√	√	√	√	√	√	√	√		√	√	√	√	√	√	
7D		√	√	√	√	√	√	√	√	√		√	√	√	√	√	√	
6D		√	√	√	√	√	√	√	√	√		√	√	√	√	√	√	
70D		√	√	√	√	√	√	√	√	√		√	√	√	√	√	√	
750D/760D		√	√	√	√	√	√	√	√	√		√	√	√	√	√	√	
5DMarkIV		√	√	√	√	√	√	√	Unavailable	√	Unavailable	√	√	√	√	√	√	
EOS 1DX		√	√	√	√	√	√	√		√		√	√	√	√	√	√	
6DMarkII		√	√	√	√	√	√	√		√		√	√	√	√	√	√	
77D		√	√	√	√	√	√	√		√		√	√	√	√	√	√	
800D		√	√	√	√	√	√	√		√		√	√	√	√	√	√	
5DMarkIII		√	√	√	√	√	√	√		√		√	√	√	√	√	√	
5DMarkII		√	√	√	√	√	√	√		√		√	√	√	√	√	√	
60D		√	√	√	√	√	√	√		√		√	√	√	√	√	√	
7D Mark II		√	√	√	√	√	√	√		√		√	√	√	√	√	√	
600D		√	√	√	√	√	√	√		√		√	√	√	√	√	√	
50D		√	√	√	√	√	√	√		√		√	√	√	√	√	Unavailable	
30D		√	√	√	√	√	√	√		√		√	√	√	√	√		
500D		√	√	√	√	√	√	√		√		√	√	√	√	√		
Digital X		√	√	√	√	√	√	√		√		√	√	√	√	√		
M3	Mirrorless Cameras	√	√	√	√	√	√	√				√		√	√	√		√
M6II		√	√	√	√	√	√	√				√		√	√	√		√
R5		√	√	√	√	√	√	√				√		√	√	√		√
R6		√	√	√	√	√	√	√	Unavailable		Unavailable	√	Unavailable	√	√	√	Unavailable	√
R6II		√	√	√	√	√	√	√				√		√	√	√		√
R7		√	√	√	√	√	√	√				√		√	√	√		√
R50		√	√	Unavailable	√	√	√	√				√		√	√	√		√
R8		√	√		√	√	√	√				√		√	√	√		√
R3		√	√		√	√	√	√				√		√	√	√		√
M5		√	√		√	√	√	√		√	√	√		√	√	√		√
M50		√	√		√	√	√	√		√	√	√		√	√	√		√ Note: Bright edges exist in wireless high-speed mode of 1/8000 (8000) /8F/P.
RP		√	√		√	√	√	√	Unavailable	√	√	√	Unavailable	√	√	√		√
R		√	√		√	√	√	√		√	√	√		√	√	√		√
1500D		√	√		√	√	√	√		√	√	√		√	√	√		√
3000D		√	√		√	√	√	√		√	√	√		√	√	√		√
200IID	SLR Cameras	√	√	√	√	√	√	√		√	√	√		√	√	√	√	√

Compatible Nikon Camera Models

Godox Camera Flashes: V1ProN、V1N、V860IIIN、V350N、TT685IIN、TT685N、TT350N
Godox Macro Flashes: MF-R76N

| Mode | Type | Camera Flashes | | | | | | | 2.4G Transmitter & Receiver Flash Units | | | | | | | Auto Focus Assist Beam | Note |
| | | TTL Flash | | | M Flash | | | Multi Flash | TTL Flash | | | M Flash | | | Multi Flash | | |
		Front-curtain Sync	Rear-curtain Sync	HSS	Front-curtain Sync	Rear-curtain Sync	HSS		Front-curtain Sync	Rear-curtain Sync	HSS	Front-curtain Sync	Rear-curtain Sync	HSS			
D800	SLR Cameras	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	
D750		√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	
D700		√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	
D610		√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	
D500		√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	
D200		√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	
D300S		√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	
D5		√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	
D4		√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	
D810		√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	
D780		√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	
D850		√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	
D5300		√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	
D5200		√	√	Unavailable	√	√	Unavailable	√	√	√	√	√	√	√	√	√	√	
D5100		√	√		√	√		√	√	√	√	√	√	√	√	√	√	
D5000		√	√		√	√		√	√	√	√	√	√	√	√	√	√	
D3300		√	√		√	√		√	√	√	√	√	√	√	√	Unavailable	√	
D3200		√	√		√	√		√	√	√	√	√	√	√	√		√	
D3100		√	√		√	√		√	√	√	√	√	√	√	√		√	
D60		√	√		√	√		√	√	√	√	√	√	√	√		√	
D7100		√	√		√	√		√	√	√	√	√	√	√	√		√	
D7500		√	√		√	√		√	√	√	√	√	√	√	√		√	
Z6	Mirrorless Cameras	√	√	√	√	√	√	√	√	√	√	√	√	√	√	Unavailable	√	
Z7II		√	√	√	√	√	√	√	√	√	√	√	√	√	√		√	
Z8		√	√	√	√	√	√	√	√	√	√	√	√	√	√		√	
ZFC		√	√	√	√	√	√	√	√	√	√	√	√	√	√		√	
Z9		√	√	√	√	√	√	√	√	√	√	√	√	√	√		√	

Compatible FUJIFILM Camera Models

Godox Camera Flashes: V1ProF、V1F、V860IIIF、V350F、TT685IIF、TT685F、TT350F

| Mode | Type | Camera Flashes | | | | | | | 2.4G主控从属闪光灯2.4G Transmitter & Receiver Flash Units | | | | | | | Auto Focus Assist Beam | Note |
| | | TTL Flash | | | M Flash | | | Multi Flash | TTL Flash | | | M Flash | | | Multi Flash | | |
		Front-curtain Sync	Rear-curtain Sync	HSS	Front-curtain Sync	Rear-curtain Sync	HSS		Front-curtain Sync	Rear-curtain Sync	HSS	Front-curtain Sync	Rear-curtain Sync	HSS			
X-Pro2	A	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	
X-T20		√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	
X-T2		√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	
X-T1		√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	
GFX50s		√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	
GFX50R		√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	
X-T30		√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	
X-T4		√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	
X-T3		√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	
X-H2		√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	
X-Pro1	B	√			√				√	√			√				√	
X-T10		√	Unavailable	Unavailable	√	Unavailable	Unavailable		√	√	Unavailable	Unavailable	√	Unavailable	Unavailable	Unavailable	√	
X-E1		√			√				√	√			√				√	
X-A3		√			√				√	√			√				√	
X100F	C	√	√	√	√	√	√	√	√	√	Unavailable		√	Unavailable	Unavailable	Unavailable		
X100T		√	√	√	√	√	√	√	√	√			√					

Compatible Sony Camera Models A

Godox Camera Flashes：TT350S、V350S

Mode	Type	机顶闪光灯Camera Flashes							2.4G Transmitter & Receiver Flash Units							Auto Focus Assist Beam	Note
		TTL Flash			M Flash			Multi Flash	TTL Flash			M Flash			Multi Flash		
		Front-curtain Sync	Rear-curtain Sync	HSS	Front-curtain Sync	Rear-curtain Sync	HSS		Front-curtain Sync	Rear-curtain Sync	HSS	Front-curtain Sync	Rear-curtain Sync	HSS			
α77II	SLR Cameras	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	
α99		√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	
α77		√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	
α350		√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	
DSC-RX10		√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	
α6000	Mirrorless Cameras	√	√	√	√	√	√	√	√	√	√	√	√	√	√	Unavailable	
α9		√	√	√	√	√	√	√	√	√	√	√	√	√	√		
α7R		√	√	√	√	√	√	√	√	√	√	√	√	√	√		
α7RII		√	√	√	√	√	√	√	√	√	√	√	√	√	√		
α7M3		√	√	√	√	√	√	√	√	√	√	√	√	√	√		
α7RIII		√	√	√	√	√	√	√	√	√	√	√	√	√	√		
α7RIV		√	√	√	√	√	√	√	√	√	√	√	√	√	√		
α7MIV		√	√	√	√	√	√	√	√	√	√	√	√	√	√		
α7R5		√	√	√	√	√	√	√	√	√	√	√	√	√	√		
α6500		√	√	√	√	√	√	√	√	√	√	√	√	√	√		
ZV-E10		√	√	√	√	√	√	√	√	√	√	√	√	√	√		

Compatible Sony Camera Models B

Godox Camera Flashes：MF-R76S/TT685S/TT685IIS/V860IIS/V860IIIS/V1S/V1ProS

Mode	Type	Camera Flashes							2.4G Transmitter & Receiver Flash Units							Auto Focus Assist Beam	Note
		TTL Flash			M Flash			Multi Flash	TTL Flash			M Flash			Multi Flash		
		Front-curtain Sync	Rear-curtain Sync	HSS	Front-curtain Sync	Rear-curtain Sync	HSS		Front-curtain Sync	Rear-curtain Sync	HSS	Front-curtain Sync	Rear-curtain Sync	HSS			
α77II	SLR Cameras	√	√	√	√	√	√	√	√	√	√	√	√	√	√	Unavailable	
α99		√	√	√	√	√	√	√	√	√	√	√	√	√	√		
α77		√	√	√	√	√	√	√	√	√	√	√	√	√	√		
DSC-RX10		√	√	√	√	√	√	√	√	√	√	√	√	√	√		
α350		√	√	√	√	√	√	√	√	√	√	√	√	√	√		
α7R	Mirrorless Cameras	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	
α6400		√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	
α6500		√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	
α6000		√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	
α7RII（4.0）		√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	
α7RIII		√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	
α7M3		√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	
α9		√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	
α7RIV		√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	
α7R5		√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	
α7MIV		√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	
ZV-E10		√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	
A9III		√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	
A7C		√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	

Compatible Olympus and Panasonic Camera Models

Godox Camera Flashes：V1ProO、V1O、V860IIIO、V350O、TT685IIO、TT685O、TT350O

Mode	Type	Camera Flashes							2.4G Transmitter & Receiver Flash Units							Auto Focus Assist Beam	Note
		TTL Flash			M Flash			Multi Flash	TTL Flash			M Flash			Multi Flash		
		Standard	2nd-C	SYNC	Standard	2nd-C	SYNC		Standard	2nd-C	SYNC	Standard	2nd-C	SYNC			
E-M1	Olympus	√	√	√	√	√	√	√	√	√	√	√	√	√	√	Unavailable	
PEN-F		√	√	√	√	√	√	√	√	√	√	√	√	√	√		
E-M10II		√	√	√	√	√	√	√	√	√	√	√	√	√	√		
E-PL8		√	√	√	√	√	√	√	√	√	√	√	√	√	√		
E-P5		√	√	√	√	√	√	√	√	√	√	√	√	√	√		
E-M10III		√	√	√	√	√	√	√	√	√	√	√	√	√	√		
GH4	Panasonic	√	√	√	√	√	√	√	√	√	√	√	√	√	√		
LX100		√	√	√	√	√	√	√	√	√	√	√	√	√	√		
DMC-GF1		√	√	√	√	√	√	√	√	√	√	√	√	√	√		
DMC-G85		√	√	√	√	√	√	√	√	√	√	√	√	√	√		
DMC-GX85		√	√	√	√	√	√	√	√	√	√	√	√	√	√		
DMC-LX100		√	√	√	√	√	√	√	√	√	√	√	√	√	√		
DMC-FZ2500GK		√	√	√	√	√	√	√	√	√	√	√	√	√	√		
S1		√	√	√	√	√	√	√	√	√	√	√	√	√	√		

Compatible Pentax Camera Models

Godox Camera Flashes：V1P、V860IIIP、TT685IIP、TT350P

Mode	Type	Camera Flashes							2.4G Transmitter & Receiver Flash Units							Auto Focus Assist Beam	Note
		TTL Flash			M Flash			Multi Flash	TTL Flash			M Flash			Multi Flash		
		Front-curtain Sync	Rear-curtain Sync	HSS	Front-curtain Sync	Rear-curtain Sync	HSS		Front-curtain Sync	Rear-curtain Sync	HSS	Front-curtain Sync	Rear-curtain Sync	HSS			
K-50	Pentax	√	√	√	√	√	√	√		Unavailable			Unavailable			√	√	√
K-S2		√	√	√	√	√	√	√								√	√	√
K-1		√	√	√	√	√	√	√								√	√	√
K-3I		√	√	√	√	√	√	√								√	√	√
645Z		√	√	√	√	√	√	√								√	√	√
KP		√	√	√	√	√	√	√								√	√	√
K-70		√	√	√	√	√	√	√								√	√	√

1. This table only lists the tested camera models, not all cameras. For the compatibility of other camera models, a self-test is recommended.
2. Rights to modify this table are retained.