
60dox



RC-A5II 遥控器 Remote Control

Instruction Manual

机身



01.电源开关键	05.+按键
02按键	06.SET按键
03.电池仓	07. LCD屏(白底黑写
O/ CH/CD###	

使田说明

1. 无线控制

RC-A5II具备控制功能, 使用433MHz无 可以分别控制6个LED摄影灯, 拥有16 组传输频道, 抗干扰性强,

使用前请将 LED 摄影灯与 RC- A5II 遥控器 短道, 组别调至一致,

2 使用遥控器调整频道/组别

- · 按CH/GR 按鈕 组别图标识纸 按"-"或"+"按键选择组别, 可选范围:
- . 按CH/CD 按钮面次 插道图标简件 按"-"或"+"按键选择频道, 可选范围: 1

3. 使用遥控器调节灯光亮度

- · 关机状态下,按住SET按键的同时长按 电源开关键,LCD屏幕出现"1"或"2",短 按SET按键选中1后;短按电源开关键开 机,短按"-"或"+"按键调节灯光亮度,调
- 遥控器色温值为3300K或色温值为 5600K时、短按"-"或"+"按键调节灯光亮 度, 调节范围: 10%-100%。
- 遥控器色温值为3400K-5500K时, 短按 "戓"+"按键调节灯光高度 调节范围
- · 关机状态下,按住SET按键的同时长按 电源开关键,LCD屏幕出现"1"或"2",短 电部开关键。ECDF养品或 1 或 2 , 粒 按SET按键选中2后,短按电源开关键开 机,短按 - 或 + 按键调节灯光亮度,调 节范围: 0%-100%。

4. 使用遥控器调节色温

 短按遥控器SET按键, 色温图标闪烁。 一"或"+"按键调节色温,调节范围;

兼容袖牛I FD摄影灯机型

	00.		LLU	100011	
+177	447 .	44 100	-		

型号	RC-A5II
供电	3V(AAA电池*2)(电池無另购)
无线频率	433MHz
频道	16个
组别	6组 (A、B、C、D、E、F)
待机时间	一年以上
工作温度环境	-10°C ~ 50°C
尺寸	120*38*15mm
净重	30a

设计和卸格加有变更 恕不呆行通知

产品保修

尊敬的用户,本保修卡是申请保修服务的 重要凭证,请您配合销售商填写并妥善保

포号	产品条码
姓名	联系电话
通信地址	
名称	
联系电话	
通信地址	
销售日期	
	姓名 通信地址 名称 联系电话 通信地址

产品信息

本文件适用于相关《产品保修信息》(见 后面说明)所列产品, 其他非属此范围的 产品或部件(如促销品、赠品及其他出厂 后附加的部件等)不在此保修承诺内。

保修期

产品及部件的相应保修期按相关的《产 品保修信息》执行。保修期自产品首次购 买日起篁 购买日以购买产品时保修卡登 记日期为准。

如何获得保修服务

您可直接与产品销售商或授权服务机构 联系,也可拨打神牛产品售后服务电话, 与我们联系, 由我们的服务人员为您安排 服务, 申请保修时, 您应提供有效的保修 卡作为保修凭证, 方可获得保修。如您不 能提供有效的保修卡,则在我们确认产品 或部件属于保修范围的情况下, 也可以为 您提供保修 但这不作为我们的义务。

不适用保修的情况

如产品存在下列情况,本文件项下的保证 和服务将不适用: ①产品或部件超过相应 保修期: ②错误或不适当使用、维护或保 管导致的故障或损坏, 如: 不当搬运; 非按 产品合理预期用途使用: 不当插拨外接设 备: 跌落或外力挤压: 接触或暴露于不适 当温度 滚剂 醉碱 水浸或潮湿环境(3) 由非神牛授权机构或人员安装、修理、更 改、添加或拆卸造成的故障或损坏; ④产 品或部件原有识别信息被修改变更或除 去;⑤无有效保修卡;⑥使用非合法授 权、非标准或非公开发行的软件造成的故 隋武揚怀: ⑦因不可抗力或音外事件造成 的故障或损坏: ⑧其他非因产品本身质量 问题导致的故障或损坏。遇上述情况,您 应向相关责任方寻求解决, 神牛对此不承 担任何责任。因非在保修期或保修范围内 的部件 附件或软件导致产品不能正常体 田的 不早保修范围内的故障 产品使用 过程中正常的脱色、磨损和消耗, 不是保 修范围内的故障。

产品保修和服务支持信息

产品的保修期和服务类型按以下《产品保 10 to 0 5 to 5.

产品类别	选件名称	保修期(月)	保修服务类型	
	主机	12	客户送修	
	电池	3	客户送修	
部件	充电器等带 电性能的部 件。	12	客户送修	
其他	如 闪光管、 造型灯泉、 外壳、 保紧等。 置、包装等。	无	无保修	

神牛产品售后服务电话 0755-29609320-8062




深圳市袖牛摄影器材有限公司

地址:深圳市宝安区福海街道塘尾社区 耀川工业区厂房2栋 电话:0755-29609320(8062) 传真:0755-25723423 邮箱: godox@godox.com

GODOX Photo Equipment Co.,Ltd.

Add.: Building 2,Yaochuan Industrial Zone, Tangwei Community, Fuhai Stree Bao'an District.Shenzhen 518103.China Tel:+86-755-29609320(8062) Fax:+86-755-25723423 E-mail: godox@godox.com godox.com Made in China

Body



Note: This product is for commercial use.

01. Power Switch

02. - Button

03. Battery Compartment 04. CH/GR Button

05. + Button

06. SET Button

07. LCD Panel (Black in White)

Operating frequency:433,05MHz -

Maximum FRP Power -12,22dBm

Declaration of Conformity GODDX Photo Equipment Co.,Ltd. hereby declares that this Remote Control/RC-A5II is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU. In accordance with Article 10(2) and Article 10(10), this product is allowed to be used in all EU member states. For more information of DoC, Please click this web link:

https://www.godox.com/DOC/Godox_RC-A5_DOC.pdf The device complies with RF specifications when the device used at 0mm from your

Operation

1. Wireless Control

With 433MHz wireless, RC-A5II has control function. Up to 6 groups of LED lights can be controlled. 16 channels are vailable with strong anti-interference capability.

Please set the channels and groups of LED light to the same as those of RC-A5II remote control before usage.

2. Adjusting Channel/Group with the Remote Control

- Press the CH/GR button and the group icon blinks. Press the"-""+"button to choose a group
- (A to F).

 Press the CH/GR button twice and the channel icon blinks ress the"-""+"button to choose a channel (1 to 16).
- 3. Adjusting Light Brightness with the Remote Control

Long press the SET button and power switch at the same time in power off status until the LCD panel displays "1" or "2", short press the SET button to choose 1, then power

- on the remote control. When the CCT value is 3300K or 5600K, short press the "-""+" button to adjust the light brightness from 10%
- · When the CCT value is between 3400K to 5500K, short press the"-""+"button to adjust the light brightness from 25% to 100%.
- Long press the SET button and Long press the SET dutton and power switch at the same time in power off status until the LCD panel displays "1" or "2", short press the SET button to choose 2. Then power on the remote control, short press he"=""+"button to adjust the light brightness from 0% to 100%

4. Adjusting Color Temperature with the Remote Control

Short press the SET button and the colo temperature icon blinks, Press the"-""+"button to adjust the color

Compatible Godox LED Lights Models JL150 and LED1000I

Model	RC-A5II
Power Supply	3V(AAA*2)(not include)
Wireless Frequency	433MHz
Channel	16
Group	6 (A, B, C, D, E, F)
Standby Time	Over one year
Working	-10°C ~ 50°C
Temperature	
Dimension	120*38*15mm
Net Weight	30g

FCC Statement

Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful

(2) this device must accept any nterference received, including nterference that may cause undesired

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment Note: This equipment has been tested

and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio requency energy and, if not installed and used in accordance with the instruction: may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the

following measures Reorient or relocate the receiving

antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help. The device has been evaluated to meet general RF exposure requirement.
The device can be used in portable exposure condition without restriction

Warranty

ar customers, as this warranty card is Dear customers, as this warranty card is an important certificate to apply for our maintenance service, please fill in the following form in coordination with the seller and safe-keep it. Thank you!

Product Information	Model	Product Code Number	
Customer	Name	Contact Number	
Information	Address		
	Name		
Seller Information	Contact Number		
	Address		
	Date of Sa	le	
Note			

Note: This form shall be sealed by the seller

Applicable Products

The document applies to the products listed on the Product Maintenance Information (see below for further information). Other products or accessories (e.g. promotional items,giveaways and additional accessories attached,etc.) are not included in this warranty scope

Warranty Period

The warranty period of products and accessories isimplemented according to the relevant Product Maintenance Information. The warranty period is calculated from the day(purchase date) when the product is bought for the first time,And the purchase date is considered as the date registered onthe warranty card when buying the product.

How to Get the Maintenance Service

If maintenance service is needed, you can directly contact the product distributor of authorized service institutions. You can

also contact the Godox after-sale service call and we will offer you service. When applying for maintenance service, you should provide valid warranty card. If you cannot provide valid warranty card, we may offer you maintenance service once confirmed that the product or accessory is involved in the maintenance scope, but that shall not be considered as our

合格证

Inapplicable Cases

obligation

The guarantee and service offered by this document are not applicable in the following cases: (1) The product or accessory has expired its warranty period; ② Breakage or damage caused by inappropriate usage, maintenance or preservation, such as improper packing, improper usage, improper plugging in/out external equipment, falling off or squeezing by external force, contacting or exposing to the improper temperature, solvent, acid, base, flooding and damp environments etc; (3) Breakage or damage caused by non-authorized institution or staff in the process of installation, maintenance, alternation, addition and detachment; ③ The original identifying information of product or accessory modified, alternated, or removed; ⑤ No valid warranty card; ⑥ Breakage or damage caused by using illegally authorized, nonstandard or non-public released software; (7) Breakage or damage caused by force majeure or accident: (8) Breakage or damage that could not be attributed to the product itself. Once met these situations above, you should seek solutions from the related responsible parties and Godox assumes no responsibility. The damage caused by parts, accessories and software that beyond the warranty

period or scope is not included in our

discoloration, abrasion and consumption are not the breakage within the maintenance scope

Maintenance and Service Support Information

The warranty period and service types of products are implemented according to the following Product Maintenance Information

Name Periodinon(h) Service Type Battery 12 Construer sends the product to product to construer sond size Circuit Board 3 Coustomer sends the product to designated size Electrical parts Coustomer sends the epiborary charger. 12 Coustomer sends the designated size			Parts		Product Type
	Flash tube, modeling lamp,lamp body, lamp	Electrical parts e.g.battery charger, etc	Circuit Board	Battery	Name
Warranty Service Type Service Type Service Type Customer sends the product to designated site Customer sends the		12	3	12	Maintenance Period(month)
	Military and the second	Customer sends the product to designated site	Customer sends the product to designated site	Customer sends the product to designated site	Warranty Service Type

Godox After-sale Service Call +86-755-29609320(8062)